

Current Replacement Parts

Note: Listed are current replacement parts that will work. See individual Detailed Model Diagrams for original part information.

Model	Burner Style	Burner (brass/nickel)	Chimney	Flame Spreader	Gallery (heel-less) (brass/nickel)	Mantle	Wick	Wick Raiser
MAXbrite 500	Side	100013606/100013607	100004908 (heel-less)	N106	N239AB/N239AN	R150 (lox-on)	N230	N233
23A	Side	100013606/100013607	100004908 (heel-less)	N106	N239AB/N239AN	R150 (lox-on)	N230	N233
23	Side	100013606/100013607	R103 (lox-on)	N106	N239AB/N239AN	R150 (lox-on)	N230	N233
21C/21	Side	100013606/100013607	R103 (lox-on)	N106	N239AB/N239AN	R150 (lox-on)	N230	N233
C	Side	100013606/100013607	R103 (lox-on)	N106	N239AB/N239AN**	R150 (lox-on)	R151	NA
B/16B	Side	100013606/100013607	R103 (lox-on)	N106	N239AB/N239AN**	R150 (lox-on)	R151	NA
A/14/16A	Side	100013606/100013607	R103 (lox-on)	N106	N239AB/N239AN**	R150 (lox-on)	R151	NA
12	Center	NA	R103 (lox-on)	N106	N239AB/N239AN**	R150 (lox-on)	N198	NA
1 through 11	Center	NA	100004908*	NA	NA	R150 (lox-on)***	N198	NA

NA = Not Available (part is no longer being made)

*Models 1-11: MAXbrite chimney may be slightly too big if gallery tabs cannot be widened

** Gallery may work for these burner models

***Models 3-11: Requires Kone Kap adapter #N146A; Models 1-2: Use an original Cap Mantle frame or construct own out of wire, then carefully remove R150 mantle from frame and apply to Cap Mantle frame or constructed wire

****Models 1-8: To fit wick, pry steel wick tabs and paper off wick

Part Adaptability

Model	Burner	Flame Spreader	Gallery	Outer Wick Tube/ Air Distributor	Wick	Wick Raiser
MAXbrite 500 series	A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	12, A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	12, A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	23/23A (some), MAXbrite	23/23A, MAXbrite	23/23A, MAXbrite
23A	A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	12, A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	12, A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	21/21C, 23/23A	23/23A, MAXbrite	23/23A, MAXbrite
23	A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	12, A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	12, A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	21/21C, 23/23A		
21C/21	A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	12, A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	12, A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	21/21C, 23/23A	21/21C	21/21C
C	A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	12, A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	12, A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	12, A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	A/14/16A, C B/16B, C	
B/16B	A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	12, A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	12, A/14/16A, B/16B	12, A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	A/14/16A, B/16B B/16B, C	
A/14/16A	A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	12, A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	12, A/14/16A, B/16B	12, A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	A/14/16A, A/14/16A B/16B, C	
12	7-12	12, A/14/16A, B/16B, C, 21/21C, 23/23A, MAXbrite	12, A/14/16A, B/16B	12	9-12	12
11	7-12	7-11	7-11	7-11	9-12	8-11
10	7-12	7-11	7-11	7-11	9-12	8-11
9	7-12	7-11	7-11	7-11	9-12	8-11
8	7-12	7-11	7-11	7-11	1-8	7-8 (9-11 w/o carrier)
7	7-12	7-11	7-11	7-11	1-8	7
6	3-6	5-6	3-6	5 (late)-6	1-8	3-6
5	3-6	5-6	3-6	5-6	1-8	3-6
4	3-6	3-6	3-6	3-5	1-8	3-6
3	3-6	3 (2 burner with 3 gallery)	3-6	3-5	1-8	3-6
2	1-2	2	1-2	2	1-8	1-2
1	1-2	1	1-2	1	1-8	1-2